



**BOLT ONTO INSIDE FENDER RAILS USING BOLTS OR THREADED STUDS.**

**IMPORTANT!**  
**MAKE SURE THERE IS ADEQUATE TIRE CLEARANCE BETWEEN THE MOUNTING HARDWARE.**

**ADJUST BRACKET ASSY. TO DESIRED POSITION.**  
**(USE LIQUID THREAD LOCKER ON ALL SCREWS)**

